Elektronic development, sales & manufacture of measurement & testing equipment








## Test earphone

**THP-12** 

Item no. 0901





Especially soft ear cushions guarantee perfect wearing comfort.

The test earphone **THP-12** can be used to test telephone lines, locate faults and trace signals. In the low-ohmic range (600 ohms), the exchange signal can be detected on analog telephone lines. On analog telephone lines, the exchange signal can be traced with a sweeping tone. For this, the **TESTOCOM 804** is used as a sweep AF transmitter, connected to the a and b conductors.

## The THP-12 is only to be used for tests in telecommunications systems in accordance with DIN VDE 0800.

In the 600  $\Omega$  range, functional tests can be performed in relay circuits.

The high-ohmmic 10-kW range is used for testing potential in high- and low-ohmic circuits and for signal tracing.

THP-12
600 Ω
10 ΜΩ
10 10122
40 Hz – 10 kHz
60 V AC/DC
260 g

